



Use and Care & Cooking Guide

Turntable Microwave Oven



Safety Instructions	3-5
Precautions to Avoid Possible Exposure to Excessive Microwave Energy	2



Operating Instructions, Tips	
Add 30 Seconds	12
Aluminum Foil	4, 18, 19
AutoDefrost.....	15, 16
Beverage	13
Child Lock-Out	10
Clock	9
Control Panel.....	89
Cook	18
Cooking by Time	11, 12
Cooking Complete Reminder	7
Cooking Guide.....	23
Defrosting by Time	14
Defrosting Guide	22
Delay Start/Reminder	12
Delayed Cooking	10
Express Cook	12
Features	7
Glossary of Microwave Terms	20
Heating or Reheating Guide	21
Hold Time	10
Kitchen Timer	10
Microwaving Tips	6
Popcorn	13
Power Levels.....	6, 10, 11
Program Cooking.....	7
Reheat	17
Sensor Cooking Control Guide	19
Sound.....	12
Turntable	3, 4, 7



Problem Solver	26
More questions ?...call	
GE Answer Center® 800.626.2000	



Care and Cleaning	24
Control Panel	24
Turntable	24



Installation	25
Adapter Plugs	25
Extension Cords	25
Grounding instructions.....	25



Consumer Services	27
Appliance Registration.....	2
Important Phone Numbers.....	27
Model and Serial Number Location	2
Warranty	Back Cover

Model: JE1250

**Microwave power output
of this oven is 1000 watts.**
(IEC-705 Test Procedure)



HELP US HELP YOU...

Before using your oven, read this guide carefully.

It is intended to help you operate and maintain your new microwave oven properly.

Keep it handy for answers to your questions.

If you don't understand something or need more help, call:

GE Answer Center®

800.626.2000

24 hours a day, 7 days a week

Write down the model and serial numbers.

You'll find them on a label inside the oven.

These numbers are also on the Consumer Product Ownership Registration Card that came with your microwave oven. Before sending in this **card**, please write these numbers here:

Model Number

Serial Number

Use these numbers in any correspondence or service calls concerning your microwave oven.

Be sure your microwave oven is registered.

It is important that we know the **location** of your microwave oven should a need occur for adjustments.

Your supplier is responsible for registering you as the owner.

Please check with your supplier to be sure he has done so; also send in your Consumer Product Ownership Registration Card. If you move, or if you are not the original purchaser, please write to us, stating model and serial numbers.

This appliance must be registered. Please be certain that it is.

write to:

GE Appliances
Range Product Service
Appliance Park
Louisville, KY 40225

If you received a damaged oven...

Immediately contact the **dealer** (or budder) that sold you the oven.

Save time and money. - Before you request service...

Check the Problem Solver in the back of this guide. It lists causes of minor operating problems that you **can correct** yourself.

All these things are normal with your microwave oven.

- Steam or vapor **escaping** from around the door.
- Light reflection around door or outer case.
- Dimming oven light and change in blower sound may occur while operating at power levels other than high.
- Dull thumping sound while oven is operating.
- Some W-Radio interference might be noticed **while** using your microwave oven. It's similar to the interference caused by other **small** appliances and does not indicate a problem with your oven.

PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

- (a) Do Not Attempt to operate this oven with the door open since open-door operation can result in harmful exposure to microwave energy. It is important not to defeat or tamper with the safety interlocks.,**
- (b) Do Not Place any object between the oven front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces...**
- (c) Do Not Operate the oven if it is damaged. It is particularly important that the oven door close properly and that there is no damage to the:**
 - (1) door (bent)
 - (2) hinges and latches (broken or loosened)
 - (3) door seals and sealing surfaces.
- (d) The Oven Should Not be adjusted or repaired by anyone except properly qualified service personnel.**

IMPORTANT SAFETY INSTRUCTIONS

Read all instructions before using this appliance.



When using electrical appliances, basic safety precautions should be followed, including the following:

⚠ **W**&To reduce the risk of burns, electric shock, fire, injury to persons or exposure to excessive microwave energy:

- Read and follow the specific "Precautions to Avoid Possible Exposure to Excessive Microwave Energy" on the previous page.
- **This appliance must be grounded.**
Connect only to properly grounded outlet.
See Grounding Instructions section in the back of this guide.
- Use this appliance only for its intended use as described in this guide. Do not use corrosive chemicals or vapors in this appliance. This microwave oven is specifically designed to heat or cook food and is not intended for laboratory or... industrial use.
- For best operation, plug this appliance into its own electrical outlet, to prevent flickering of lights, blowing of fuse or tripping of circuit breaker.
- Install or locate this appliance only in accordance with the provided Installation Instructions.
- Be certain to place the front of the door three inches or more back from the countertop edge to avoid, accidental tipping of the appliance in normal usage.
- Do not cover or block any openings on the appliance.
- Do not store this appliance outdoors. Do not use this product near water—for example, in a wet basement, near a swimming pool or near a sink.
- This microwave oven is not approved or for marine use.
- Do not immerse power cord or plug in water.
- Keep power cord away from heated surfaces.
Do not operate any heating or cooking appliance beneath this microwave oven.
- Do not mount the microwave oven over or near any portion of a heating cooking appliance.
- Do not store anything directly on top of the microwave oven surface when the microwave oven is in operation.
- Do not let power cord hang over edge of table or counter.
- Do not operate this appliance if it has a damaged power cord or plug, if it is not working properly or if it has been damaged or dropped.
- Do not operate oven without the turntable and turntable support seated and in place.
- Do not allow turntable to be restricted so the turntable cannot rotate.
- See door surface cleaning instructions in the Care and Cleaning section(s) of this guide.
- This appliance should be serviced only by qualified service personnel. Contact nearest authorized service facility for examination, repair or adjustment.
- As with any appliance, close supervision is necessary when used by children.
- To reduce the risk of fire in the oven cavity:
 - Do not overcook food. Carefully attend appliance if paper, plastic or other combustible materials are placed inside the oven to facilitate cooking.
 - Remove wire twist-ties and metal handles from paper or plastic containers before placing them in the oven.
 - Do not use your microwave oven to dry newspapers.
 - Do not use recycled paper products. Recycled paper towels, napkins and waxed paper can contain metal flecks which may cause arcing or ignite. Paper products containing nylon or nylon filaments should be avoided, as they may also ignite.
 - Do not pop popcorn in your microwave oven unless it is in a special microwave popcorn accessory or unless you use popcorn labeled for use in microwave ovens.
 - Do not overcook potatoes. They could dehydrate and catch fire, causing damage to your oven.

continued next page)



IMPORTANT SAFETY INSTRUCTIONS

(continued)

- Do not operate the oven while empty to avoid damage to the oven and the danger of fire. If by accident the oven should run empty a minute or two, no harm is done. However, try to avoid operating the oven empty at all times—it saves energy and prolongs the life of the oven.
 - Do not use the oven for storage purposes. Do not leave paper products, cooking utensils or food in the oven when not in use.
 - If materials inside oven should ignite, keep oven door closed, turn oven off and disconnect power cord, or shut off power at the fuse or circuit breaker panel.
-
- Some products such as whole eggs and sealed containers—for example, closed jars—will explode and should not be heated in this microwave oven. Such use of the microwave oven could result in injury.
 - Avoid heating baby food in glass jars, even with the lid off. Make sure all infant food is thoroughly cooked. Stir food to distribute the heat evenly. Be careful to prevent scalding when warming formula or breast milk. The container may feel cooler than the milk really is. Always test the milk before feeding the baby.
 - Do not defrost frozen beverages in narrow necked bottles (especially carbonated beverages). Even if the container is opened, pressure can build up. This can cause the container to burst, possibly resulting in injury.
 - Use foil only as directed in this guide... TV dinners maybe microwaved in foil trays less than 3/4" high; remove the top foil cover and return the tray to the box. When using foil in the microwave oven, keep the foil at least 1 inch away from the sides of the oven.
 - Cookware may become hot because of heat transferred from the heated food. Pot holders may be needed to handle the cookware.
 - Sometimes, the turntable can become too hot to touch. Be careful touching the turntable during and after cooking.
-
- Foods cooked in liquids (such as pasta) may tend to boil over more rapidly than foods containing fat & moisture. Should this occur, refer to the Care and Cleaning section(s) for instructions on how to clean the inside of the oven.
 - Thermometer—Do not use a thermometer in food you are microwaving unless the thermometer is designed or recommended for use in the microwave oven.
 - Plastic cookware—Plastic cookware designed for microwave cooking is very useful, but should be used carefully. Even microwave-safe plastic may not be as tolerant of overcooking conditions as are glass or ceramic materials and may soften or char if subjected to short periods of overcooking. In longer exposures to overcooking, the food and cookware could ignite. For these reasons:
 - 1) Use microwave-safe plastics only and use them in strict compliance with the cookware manufacturer's recommendations.
 - 2) Do not subject empty cookware to microwaving.
 - 3) Do not permit children to use plastic cookware without complete supervision.
-
- When cooking pork, follow the directions exactly and always cook the meat to an internal temperature of at least 170°F. This assures that, in the remote possibility that trichina maybe present in the meat, it present in the meat, meat will be safe to eat.
 - Do not boil eggs in a microwave oven. Pressure will build up inside egg yolk and will cause it to burst, possibly resulting in injury.
 - Foods with unbroken outer "skin" such as potatoes, sausages, and other giblets and egg yolks (See previous caution) should be pierced to allow steam to escape during cooking.





• **Spontaneous boiling**—Under certain special circumstances, liquids may start to boil during or shortly after removal from the microwave oven. To prevent burns from splashing liquid, allow the container to stand in the oven for 30 to 40 seconds after the oven has shut off.



• **Hot foods and steam can cause burns.** Be careful when opening any containers of hot food, including popcorn bags, cooking pouches and boxes. To prevent possible injury, direct steam away from hands and face.

• **“Boilable” cooking pouches and tightly closed plastic bags** should be slit, pierced or vented as directed by package. If they are not, plastic could burst during or immediately after cooking, possibly resulting in injury. Also, plastic storage containers should be at least partially uncovered because they form a tight seal. When cooking with containers tightly covered with plastic wrap, remove covering carefully and direct steam away from hands and face.

• **Not all plastic wrap is suitable for use in microwave ovens.** Check the package for proper use..

SAVE THESE INSTRUCTIONS

IF YOU NEED SERVICE...

To obtain service, see the Consumer Services page in the back of this guide.

We're proud of our service and want you to be pleased. If for some reason you are not happy with the service you receive, here are three steps to follow for further help.

FIRST, contact the people who serviced your appliance. **Explain** why you are not pleased. In most cases, this will solve the problem.

NEXT, if you are still not pleased, write **all** the detail—including your phone number—to:

Manager, Consumer Relations
GE Appliances
Appliance Park
Louisville, KY 40225

FINALLY, if your problem is still not resolve& write:

Major Appliance Consumer Action Panel
20 North Wacker Drive
Chicago, IL 60606





MICROWAVING TIPS

• **Make sure all cookware used in your microwave oven is suitable for microwaving.** Most glass casseroles, cooking dishes, measuring cups, custard cups, pottery or china dinnerware which does not have metallic trim or glaze with a metallic sheen can be used. Some cookware is labeled “suitable for microwaving”.

• **If you are not sure if a dish is microwave-safe, use this test:** Place in the oven both the dish you are testing and a glass measuring cup filled with one cup water—set the measuring cup either in or next to the dish. Microwave 1 minute at high. If the dish heats, it should not be used for microwaving. If the dish remains cool and **only** the water in the cup heats, then the dish is microwave-safe.



• **Paper towels, waxed paper and plastic wrap** can be used to cover dishes in order to retain moisture and prevent spattering. Be sure to vent plastic wrap so steam **can escape**.

• **Some microwaved foods require stirring, rotating or rearranging.** Check the Cooking Guide.

• **Steam builds up pressure in foods which are tightly covered by a skin or membrane.** Pierce potatoes, egg yolks and chicken livers to prevent bursting.

If you use a meat thermometer while cooking, make sure it is safe for use in microwave ovens.

VARIABLE POWER LEVELS (1-10)

Variable power levels add flexibility to your microwave rooking. The power levels on your microwave oven can be compared to the **surface** units on a range. **HIGH** (Power Level 10) or full power is the fastest way to cook and gives you 100% power. Each power level gives you microwave energy a certain percent of the time. Power Level 7 is microwave energy 70% of the time. Power Level 3 is energy 30% of the time.


A high setting (10) **will** cook faster but may need additional attention such as frequent stirring, rotating or turning over. Most of your rooking will be done on **HIGH** (Power Level 10). A lower setting **will** cook more **evenly** and with less attention given to stirring or rotating the food. Some foods may have better flavor, texture or appearance if one of the lower settings is used. You may wish to use a lower power level when cooking foods that have a tendency to boil over, such as **scalloped** potatoes.

Rest periods (when the microwave energy cycles **off**) give time for the food to “**equalize**” or transfer heat to the inside of the food. An example of this is shown with Power Level 3—the defrost cycle. **If** microwave energy did not cycle off, the outside of the food would cook before the inside was defrosted.

Here are some examples of uses for various power levels:

POWER LEVEL	BEST USES
High 10	Fish, bacon, vegetables, boiling liquids.
Meal-High 7	Gentle cooking of meat and poultry ; baking casseroles and reheating.
Medium 5	Slow cooking and tenderizing such as stews and less tender cuts of meat.
Low 2“ or 3	Defrosting without cooking; simmering; delicate sauces.
warm 1	Keeping food warm without overcooking ; softening butter.

FEATURES OF YOUR OVEN



1. **Door Latches.**
2. **Door Screen.** Metal screen permits viewing of foods and keeps microwaves confined inside oven.
3. **Automatic Cooking Guide.** Quick reference codes for many **frequently** prepared foods.
4. **Touch Control Panel and Display.** See Your Touch Control Panel section for instructions.

5. **Removable Turntable Support for Cleaning.** Turntable support must be in place when using the oven.
6. **Removable Turntable for Cleaning.** Turntable and support **must** be in place when using the oven. The turntable may be removed for cleaning.
7. **Door Latch Release.** Press latch release button to open door.

NOTE: Rating plate, oven vent(s) and oven light are **located** on the inside walls of the microwave oven.

Program Cooking


Use your Touch Control Panel to Time Defrost or Micro Cook **with choice** of power levels from 1 (lowest) to 10 (**highest**); to time kitchen tasks with the **Kitchen Timer**; and to set the clock.

Create your own programs to suit your **individual** rooking style. For **example**: use the **Kitchen Timer** to delay the start of Micro Cook or program a hold time between Time Defrost and Micro Cook. Set Micro Cook for a two-stage program using different times and power levels.

-Cooking Complete Reminder

@or **Micro Cook and Time Defrost cycles)** .

To remind you that you have food in the oven, **the** oven will beep once a minute until you either open the oven **door** or touch the **CLEAR/OFF** pad.



YOUR TOUCH CONTROL PANEL



The Touch Control Panel allows you to set the oven controls with the touch of a finger. It's designed to be easy to use and understand.

1. **DISPLAY.** Displays time of day, cooking time, power level being **used**, cooking mode and instructions.
2. **POPCORN.** Touch this pad to cook prepackaged microwave popcorn weighing 3.0 to 3.5 ounces. No need to touch **START**, the oven will start immediately.
3. **REHEAT.** Touch this pad for quick reheating of prepared foods. No need to touch **START**, the oven will start immediately.
4. **MICRO COOK** Microwave for a selected amount of time using automatic Power Level 10 (**High**).
5. **EXPRESS COOK** Touch number pads 1 through 5 for 1 to 5 minutes of cooking. No need to touch **START**, the oven will start immediately.
6. **NUMBER PADS.** Touch these pads to program the microwave.
7. **POWER LEVEL.** Touch this pad before entering another power level number **if** you want to change from automatic Power Level 10 (**High**) for cooking or Power Level 3 (**Low**) for defrosting.
8. **SOUND.** Touch the **SOUND** pad to turn the oven beeper on or off.
9. **KITCHEN TIMER.** This feature uses no microwave energy. It functions as either a kitchen timer, as a holding period after defrost or as a delay timer before time cooking.
10. **BEVERAGE.** Touch this pad to heat or reheat a beverage. No need to touch **START**, the oven will start immediately.
11. **COOK** Touch this **pad**, the number pad for the desired code number and **START**. The oven automatically microwaves at pre-programmed power levels and determines the proper amount of cooking times **until** the food is done and oven shuts **Off**.
12. **TIME DEFROST.** Gentle thawing at automatic Power Level 3 (**Low**).
13. **AUTO DEFROST.** Touch this pad and food **weight**, then **START**. The oven automatically sets power levels and defrosting time.
14. **START.** After all selections are made, touch this pad to start the oven.
15. **DELAY START/REMINDER.** Allows you to program your oven to begin cooking at a preset time of day-up to a 12-hour **delay**. The Reminder feature can be used like an **alarm** clock.
16. **CLEAR/OFF.** When touched, it shuts off the oven and erases **all** settings (except time of day). When held for three seconds, the **Child Lock-Out** feature will be activated. To deactivate, press and hold the **CLEAR/OFF** pad for three seconds.
17. **ADD 30 SECONDS.** Press this pad for 30 seconds of cook time, to add 30 **seconds** to the **cook** time as it's counting down or for an "instant on" for 30 seconds.
18. **CLOCK.** Touch this pad to enter time of day or check time of day **while** microwaving. To set **clock**, first touch **CLOCK** pad and then enter time of day. For example, if time is 1:30, touch number pads 1,3 and 0 and "1:30" will **appear in display**. Then touch **START** or **CLOCK pad**. To reset or change time, simply repeat above process.

When You Plug in the Oven

The display panel displays "88888", "18 **POWER**" and **all of the oven** functions. After 15 seconds, **all** lights disappear and "RESET" appears in the upper portion. Touch the **CLEAR/OFF pad**, set the Clock and the oven is ready for use.

This will happen any time there is a power outage.



HOW TO USE THE KITCHEN TIMER

The Kitchen Timer

The Kitchen Timer has three timing functions:

- It operates as a minute timer.
- It can be set to delay cooking.
- It can be used as a hold setting after defrosting.

The Kitchen Timer operates without microwave energy.

Using a Holding Time

The Kitchen Timer can **also** be used to program a “holding time” between microwave cooking functions. The time **can** range from one second to 99 minutes and 99 **seconds**. A holding or standing time maybe found in some of your own recipes or in a **cookbook**.

How to Time a 3-Minute Phone Call



Step 1: Touch KITCHEN TIMER pad.

Step 2: Touch number pads 3,0 and O (for 3 minutes and no seconds).



Step 3: Touch START. Display shows time **counting** down. The timer signals when time is up.

Programming Delayed Cooking

To delay cooking up to 99 minutes and 99 seconds, touch MICRO COOK and enter cook time. Touch KITCHEN TIMER and enter number of minutes to delay rooking. Touch START. Timer **will** count down to zero and cooking **will** begin.

How to Defrost, Hold and Micro Cook

Let's say you want to defrost a frozen casserole for 15 minutes, hold for 10 minutes and then Micro Cook for 25 minutes. Here's how to do it:

Step 1: Take casserole from freezer and place in oven.

Step 2: Touch TIME DEFROST.

TIME
DEFROST

Step 3: Touch pads 1,5,0 and O for 15 minutes defrosting time. Defrosting is **automatically** set on Power Level 3 but can be changed by touching the POWER LEVEL pad and the desired power level 1-10.

Step 4: Set standing or hold time by touchin_g KITCHEN TIMER.



Step 5: Touch 1,0,0 and O to hold for ten minutes.



Step 6: Touch MICRO COOK

Step 7: Touch 2,5,0 and O for 25 minutes of cooking time.



Step 8: Touch START. As each function is **automatically performed**, oven display shows instructions entered and the function. **When** time is up, the oven signals and flashes “End”.

CHILD LOCK-OUT

You may lock the control panel to prevent the microwave from being **accidentally** started or used by **children**.



To lock the controls press and hold the CLEAR/OFF pad for about three seconds. The display will show LOCK and then return to the time of day. A **small “L”** will be displayed to retinal you that the **control** panel is locked.

If anyone tries to use the microwave, the display **will** show LOCK

To **unlock** the control panel press and hold the CLEAR/OFF pad for about three seconds.

The display will show the time of day.

COOKING BY TIME




Micro Cook I

Micro Cook allows you to microwave for a preset amount of time.

Power **Level 10 (High)** is recommended for most cooking, but you may change this for more flexibility. See the Cooking Guide.

To become better acquainted with time cooking, make a cup of coffee by following the steps below.

Step 1: Fill a cup 2/3 full of water, add 1 teaspoon of instant coffee and stir to dissolve. Use a cup that has no metal decoration and is **microwave-safe** (refer to



Microwaving Tips section).

Plain cup in oven and close door.



Step 2: Touch MICRO COOK

Step 3: Select your time. Touch pads 1,0 and O for 1 minute.

Because automatic Power **Level 10** is **recommended** for this cup of coffee, there is no need to change the power level. (If Power **Level 10** is not appropriate, see "How to Change Power **Level**" below.)



Step 4: Touch START.

Step 5: When time is up, the oven signals and flashes "End". The oven, light and fan shut off.

Step 6: Open the door.

If you **interrupt** Micro Cook to check the **food**, simply close the door and press **START** to resume cooking. If there is not time remaining on the timer you must reset the timer to resume cooking.

How to Change Power Level When Setting Micro Cook I

1. Press MICRO COOK
2. Select cooking time.
3. Press **POWER LEVEL**.
4. Select desired power level 1-10.
5. Press **START**.



Using the Micro Cook II Feature

The Micro Cook II feature lets you set 2 time cooking functions within one program. This is **ideal** if you want to change power levels during your rooking operations. Here's how to do it.

Step 1: Place the food in the oven in a **microwave-safe** container and close the door.



Step 2: Touch MICRO COOK

Step 3: Select your first cook time. For example, touch 2, 1 and 5 for 2 minutes and 15 seconds.

Step 4: Now is the time to change the power level if you don't want full power for MICRO COOK. (Press **POWER LEVEL**. Select desired power level 1-10.)

Step 5: Touch MICRO COOK again.

Step 6: Set your second cook time.

Step 7: Change the power level for MICRO COOK. (Press **POWER LEVEL**. Select desired power level 1-10.)

Step 8: Press **START**.



The **microwave** oven will start and the time set for "COOK TIME I" will count down. Also, "POWER 10" or the power level selected for "COOK TIME I" will be displayed.

At the end of "COOK TIME I", the second power level is displayed and the time for "COOK TIME II" is shown counting down.

When time is up, the oven **signals** and flashes "End". The oven, light and **fan** shut off. Open the door.

If you **interrupt** Micro Cook to check the **food**, simply close the door and press **START** to resume cooking. If there is no time remaining on the timer you must reset the timer to resume cooking.

(continued next page)




COOKING BY TIME

(continued)

The Express Cook Feature

The Express Cook feature is a short-cut method to set time for 1-5 minutes at Power Level 10.



To Express **Cook** your food or beverage:

Touch a number pad (from 1 to 5) for 1 to 5 minutes of **cooking** at Power **Level** 10. For example, touch the 2 pad for 2 minutes of cooking time. No need to touch **START**, the oven will start immediately.

The oven will signal and turn off automatically when finished.

How to Use Delay Start

The Delay Start feature allows you to program your oven to begin cooking at a pre-set time of day—up to a 12-hour delay.



Step 1: Touch DELAY START pad.

Step 2: Enter the time you want the oven to start. (Be sure your microwave oven clock shows the correct time of day.)

Step 3: Enter your desired cooking program.



Step 4: Touch **START** pad. The display will show the time you entered. The time of day may be displayed by touching the **CLOCK** pad. The oven will **automatically** start at the desired time.

How to Use Reminder

The Reminder feature can be used like an **alarm clock**, without starting the oven.


Example: It is 7 a.m. and you must remember to leave for a dentist appointment at 10 a.m.



Step 1: Touch DELAY START pad.

Step 2: Enter the time you want the oven to remind you. (Be sure your microwave oven clock shows the correct time of day. The reminder time **can** be set up to 12 hours later.)

Step 3: Touch **START** pad. The reminder is set at the time you programmed, and will signal you at that time with a beeping sound until



you open the door or touch the **CLEAR/OFF** pad. The display will show “REM” until the oven door is opened or **CLEAR/OFF** is touched. The **REM**inder time may be displayed by touching the **DELAY START** pad. The time-of-day maybe displayed by touching the **CLOCK** pad.

Add 30 Seconds



The Add 30 Seconds feature provides a convenient way to extend cooking time by 30 seconds while the oven timer is counting down. It will add 30 seconds to the time shown each time the pad is touched.

This pad **may also** be used as an express **cook** for 30 seconds of cooking. No need to touch **START**, the oven will start immediately.

Sound Feature

The Sound feature allows you to turn the oven beeper on or off.

Touch the **SOUND** pad once for sound. Touch the pad again for no sound. If the sound has been turned off, the display will show “OFF” and then return to the time of day. A small “NO SOUND” will be displayed. —

POPCORN



The Popcorn feature is designed to be used **only** with prepackaged microwave popcorn weighing 3.0 to 3.5 ounces.

Step 1: Remove the outer wrapper from the microwave popcorn.

Step 2: Open oven door and place package of popcorn in the center of the oven floor as directed by the package instructions. Close oven door.

POPCORN

Step 3: Touch POPCORN pad. No need to touch **START**, the oven will start immediately.

After the popcorn sensor detects steam, the oven signals and displays remaining cooking time needed.

: 20:10
COOK TIME POWER

Step 4: When cooking is **completed**, the oven signals and flashes "End". Open the door and remove the popcorn.

End

How to Adjust the Popcorn Program to Provide a Shorter or Longer Cook Time

If your favorite popcorn is not completely **popped**, there is a simple adjustment you **can** make.

Touch the POPCORN pad. (The oven will start immediately.) Then touch number pad 9. A plus sign will appear on the display beside the word "POP".

The plus sign indicates 20 seconds more cooking time is being provided.

POP +

If your favorite popcorn is **overcooked**, there is a simple adjustment you can make.

Touch the POPCORN pad. (The oven will start immediately.) Then touch number pad 1. A minus sign will appear on the display beside the word "POP".

The minus sign indicates 20 seconds less cooking time is being provided.

POP -

Questions and Answers

Q. I opened the door to check on the popcorn and "Error" appeared on the display. Why?

A. The Popcorn program first detects steam and then switches to Time Cook. **If** you open the door **while** "POP" is **displayed**, "Error" will appear. Close the door, touch **CLEAR/OFF** and begin again. You may open the door when "End" appears on display.

Q. Can I use regular popcorn with the Popcorn feature in my microwave oven?

A. No. This automatic function is designed to be used **only** with prepackaged microwave popcorn.

BEVERAGE

The Beverage program makes it simple to heat a cup of hot chocolate or other beverage. Use a cup that has no metal decoration and is microwave-safe (refer to the Microwaving Tips section).

BEVERAGE

Touch **BEVERAGE** pad. No need to touch **START**, the oven will start immediately.

The oven will signal and turn off automatically when finished.

CAUTION: Beverages heated with the Beverage feature may be quite **hot**. Remove the container with care.



DEFROSTING BY TIME

Time Defrost (Power Level 3)

Time Defrost is designed for speedy thawing of frozen food and is one of the great advantages of a microwave oven.

Use the Time Defrost setting to **quickly** thaw foods such as bread, rolls, vegetables, fruits and frozen dinners. The Auto Defrost setting is preferred for meat and **poultry** because the oven sets the defrosting time and power levels for you.

- Power **Level 3** is **automatically** set when you press **TIME DEFROST** pa& but you may change this for more flexibility.
- See the Defrosting Guide for defrosting help.

How to Change Power Level

1. Press **TIME DEFROST**.
2. Select defrosting time.
3. Press **POWER LEVEL**.
4. Select desired power level 1-10.



To become better acquainted with the defrost **function**, defrost a 10 oz. package of frozen strawberries by following the steps below.

Step 1: Place a package of frozen strawberries in the oven and close door. Be sure package contains no metal.



Step 2: Touch **TIME DEFROST**.

Step 3: Select one **half** of the **total** defrosting time recommended. For example, touch pads 4, 0 and 0 for 4 minutes.



Step 4: Touch **START**. **When** the cycle is **completed**, the oven **signals** and flashes “End”, then automatically shuts off.

Step 5: Turn the package over, close the door and repeat Steps 2 and 3 to set remaining **half** of defrosting time. Touch **START**.

Step 6: **When** the oven signals and flashes “End”, open the door, remove the package and separate strawberries to finish defrosting.

Defrosting Tips



- Foods frozen in **paper** or **plastic** can be defrosted in the package. **Tightly closed packages** should be slit **pierced** or vented & R food has **partially defrosted**, as directed by package. Plastic storage containers **should** be at least partially uncovered.

- Family-size, pre-packaged frozen dinners can be defrosted and microwaved. **If** the food is in a **foil** container, transfer it to a microwave-safe dish.



- For even defrosting, some foods need to be broken up or separated part of the way through the defrosting time.
- Foods that spoil easily, such as **milk**, eggs, fish, stuffings, **poultry** and pork **should** not be allowed to sit out for more than one hour after defrosting. Room temperature promotes the growth of harmful bacteria.
- **Check** the Defrosting Guide for other defrosting tips.

Questions and Answers

Q. When I press START, I hear a dull thumping noise. What is it?

A. This sound is normal. It is letting you know the magnetron is in operation.

Q. Can I defrost small items in a hurry?

A. Yes, but they **will** need more frequent **attention** than usual. Raise the power level after entering the time by touching the desired power level pad. Power **Level 7** cuts the total defrosting time in — about 1/2; Power **Level 10** **cuts the total defrosting** time to approximately 1/3. During either, rotate or stir food frequently.

AUTO DEFROST



Auto Defrost

With the Auto Defrost feature, the oven automatically sets the defrosting times and power levels for you.

Use the Auto Defrost Guide. Enter the food weight in pounds and tenths of a pound (see Conversion Guide below). Then touch **START** pad.

The oven **calculates** defrosting time and changes power levels during defrosting to give even defrosting results.

How to Set Auto Defrost

Before you begin, check the guide located on the inside front of oven when you open the door.

It shows minimum and maximum food weights for a variety of foods. You **will** need to know your food weight before setting Auto Defrost.

Step 1: Remove food from package, place in oven on microwave-safe dish and close door.




Step 2: Touch AUTO DEFROST pad.

Step 3: Enter weight. For example, touch number pads 1 and 2 for weight of 1.2 pounds (1 **pound**, 3 ounces). See Conversion Guide below. After approximately 5 seconds "START" flashes.



Step 4: Touch **START** pad. Display shows defrost time counting down.

Twice during defrosting, the oven beeps 4 times and "TURN" flashes. Follow the directions in the Auto Defrost Guide for what to do at the first and second signal. Then close the door and touch **START** pad.



When defrosting time is **completed**, "End" flashes and oven beeps 4 times. "End" remains on display and oven beeps every minute **until** door is opened or **CLEAR/OFF** pad is touched.

Stand Time

After Auto Defrosting, meat needs to stand in order to let the inside defrost. You **may** take the food out of the oven if you wish. Stand time **recommendations** are given in the Auto Defrost Guide.

Conversion Guide

If the weight of food is stated in pounds and ounces, the ounces must be converted to tenths (.1) of a pound.	
Ounces	Pounds
1-2	.1
3	.2
&5	.3
6-7	.4
8	.5
9-10	.6
11	.7
12-13	.8
14-15	.9



AUTO DEFROST GUIDE

RECOMMENDED FOODS	MIN.-MAX. WEIGHT	FIRST SIGNAL	SECOND SIGNAL	ST_ TIME
Chops	0.1- 6.0 lbs.	Turn over.	Separate and shield where necessary.	5 minutes
Frankfurters, Sausage	0.1 -6.0 lbs.	Separate.	Remove defrosted pieces.	2 minutes
Ground Meat	0.1- 6.0 lbs.	Turn over.	Remove defrosted areas and break apart .	5 minutes
Beef Patties	0.1- 6.0 lbs.	Turn over.	Separate patties.	5 minutes
Roast	0.1- 6.0 lbs.	Turn over and shield.	Shield if necessary.	30 minutes
Ribs	0.1- 6.0 lbs.	Turn over.	Remove defrosted pieces. Shield if necessary.	10 minutes
Steak	0.1 - 6.0 lbs.	Turn over.		5 minutes
Stew	0.1- 6.0 lbs.	Turn over and separate .	Separate and remove defrosted pieces .	5 minutes
Poultry				
Whole Chicken	0.1- 6.0 lbs.	Turn over and shield.	Turn over and shield	10 minutes; run cold water in cavity .
Turkey Breast (breast side up)	0.1- 6.0 lbs.	Turn over.	Shield where necessary.	20 minutes; run cold water in cavity .
Chicken Pieces	0.1- 6.0 lbs.	Turn over.	Separate and remove defrosted pieces .	5 minutes
Cornish Hens (whole)	0.1- 6.0 lbs.	Remove wrapper and turn over.		10 minutes; run cold water in cavity.
Cornish Hens (split)	0.1- 6.0 lbs.	Turn over.		5 minutes
Seafood				
Fish Fillets	0.1- 6.0 lbs.	Turn over.	Separate and remove defrosted pieces.	5 minutes
shrimp , Scallops	0.1- 6.0 lbs.	Separate.	Separate and remove defrosted pieces.	5 minutes
Whole Fish	0.1- 6.0 lbs.	Turn over and shield tail and head.		Hold under cold running water.

Edges or thin areas of meat **will** defrost more **rapidly** than other areas.
After first or second signal, shield warm areas with small **pieces** of foil.

REHEAT



Reheat lets you touch just one pad to bring previously prepared foods to serving temperature. With many leftovers, there is no need to lookup reheating times in a cookbook or to rely on guesswork.

By actually sensing the steam that escapes as food heats, this feature automatically adjusts the oven's heating time **to** various types and amounts of **pre-cooked** food.

Because **all** cooking containers must be covered during reheating, this feature is best with foods you want to steam or retain **moisture**.

Foods Recommended

A wide variety of previously prepared foods including leftovers **can** be reheated using this feature, Reheat is **recommended** for single-servings of food or plates of leftovers.

Foods Not Recommended

Bread products, foods that must be reheated **uncovered**, foods that require constant attention, and foods **calling** for a dry look or crisp surface after reheating should not be reheated **using** this feature. It is best to use Micro Cook.

Easy to Use

Simply touch the **REHEAT** pad.

No need to touch the **START** pad, the oven **will** start immediately.

Keep Door Closed

Do not open the oven door while the word "**RHEAT**" is **displayed**—**steam** escaping from the oven can Meet reheating performance. If the door is **opened**, close the door and touch **START** immediately.

Example:




Place covered food in the oven. Touch the **REHEAT** pad. No need to touch the **START** pad, the oven **will** start immediately.

"**RHEAT**" and "**FOOD**" are displayed.



Beep sounds when **steam** is sensed and "**RHEAT**" is replaced by **time counting down**. Rotate or stir food if necessary. Close door and touch **START** to finish heating. When done, oven displays "**End**" and beeps every minute **until** door is opened or **CLEAR/OFF** is touched.



CAUTION: Reheated foods **may** have wide variations in temperature. Some **areas** may be extremely hot. After removing food from the **oven**, we recommend that **all** reheated foods be **stirred**, if possible, to even out the temperature.

Questions and Answers

Q. What if I don't fully cover the dish in Reheat?

A. Oven senses steam too **quickly**, which shortens the reheating time and leaves food too cool. Cover tightly and reset Reheat.

Q. If my food is not completely reheated after using Reheat, what should I do?

A. Use Micro Cook to reheat for additional time **until** desired temperature is reached.



COOK

The Cook feature makes cooking your favorite foods easy. By actually sensing the steam that escapes as food cooks, this **feature automatically** adjusts the oven's cooking time to various types and amounts of food.

Because most cooking containers must be covered during **Cook**, this feature is best with foods that you want to steam or retain moisture.

Foods Recommended

A wide variety of foods including meats, fish and vegetables can be cooked using this feature.

Foods Not Recommended

Foods that must be **cooked uncovered**, foods that require constant **attention**, foods that require addition of **ingredients** during **cooking** and foods **calling** for a dry look or crisp **surface** after cooking **should** not be cooked using this feature. It is best to **Micro Cook** them.

Easy to Use

Simply touch 3 control **pads**—**COOK**, desired **CODE** and **START**. The word “**AUTO**” appears on **the** display and the sensor is activated to sense steam from food.

Keep Door Closed

Do not open the oven door while the word “**AUTO**” is display **ed**—**steam** escaping from the oven **can** affect cooking performance. If the door is **opened**, close the door and touch **START** immediately.

Cook Codes

Cook codes 1 through 7 are designed to give you easy, automatic results with a number of **popular** foods. See the Sensor Cooking Control Guide section for specific foods and instructions.


Example:




Step 1: Place covered food in oven. Touch **COOK pad**. “**ENTER FOOD CODE**” flashes on **display**.

Step 2: Touch number pad of desired food code. The code and food type you selected **will** appear on the display. “**FOOD**” and “**CODE**” flash. After 5 seconds, “**START**” flashes on the display. Touch **START**.

The word “**AUTO**” shows on display, indicating steam sensor is activated. **DO NOT OPEN DOOR. OPENING DOOR MAY AFFECT COOKING PERFORMANCE.**



Beep sounds when steam is sensed and “**AUTO**” is replaced by cook time. Rotate or stir food, if necessary. When done, oven **beeps** every minute until door is opened or **CLEAR/OFF** is touched.



REHEAT AND COOK CONTAINERS AND COVERS



Containers and Covers

Appropriate containers and coverings help assure good cooking results.

- **Always** use microwave-safe **containers** and cover them with lids or vented plastic wrap. Wonder if it's microwave-safe? Put it to the test described in the Microwaving Tips section.
- Match the amount of food **to** the size of the container. Fill containers at least **half** full for best results.

- **Never use tight-seating plastic covers—** they can prevent steam from escaping and cause food to overcook.
- **Be sure the outside of the cooking container and the inside of the microwave oven are dry** before placing food in the oven. Beads of moisture turning into steam can mislead the sensor.
- Stir or rotate some foods **after** a beeping signal, if required. See the Sensor Cooking Control Guide section.

SENSOR COOKING CONTROL GUIDE

- Do not open oven door during cycle. When oven **signals** and countdown time is displayed, door may **be opened** for stirring, turning or **rotating** food. To resume cooking, close door and touch **START**.
- Be sure outside of container and inside of oven are dry.
- Match the amount of food to the size of container. Fill containers at least 1/2 full.
- After completion of Cook cycle, if food needs **additional** cooking, return food to oven and use Micro Cook to **finish** cooking.

Food	Cook Code	Servings	Serving Size	Comments
Canned Vegetables	1	1 to 4	4 oz.	Use microwave-safe casserole or bowl. Cover with lid or plastic wrap .
Frozen Vegetables	2	1 to 4	4 oz.	Use microwave-safe casserole or bowl. Follow package instructions for adding water. Cover with lid or plastic wrap.
Fresh Vegetables	3	1 to 4	4 oz.	Use microwave-safe casserole or bowl. Add 2 tablespoons water for each serving. Cover with lid or plastic wrap.
Potatoes	4	1 to 4	8 oz.	Pierce skin with fork. Cluster potatoes in center of oven floor.
Fish	5	1 to 4	4 oz.	Use oblong, square or round dish. Cover with plastic wrap.
Chicken Pieces	6	1 to 4	1 to 2 pieces	Use oblong, square or round dish. Cover with wax paper.
Ground Meat (Beef, Pork, Turkey)	7	—	1/2 to 3 lbs.	Use round casserole dish. Crumble meat into dish. Cover with wax paper or plastic wrap.



GLOSSARY OF MICROWAVE TERMS

When adapting recipes for the microwave, it is best to start with a **familiar recipe**. **Knowing** how the food should look and taste **will help** when adapting recipes for microwaving. Foods that require browning or crisp, dry surfaces will cook better in regular ovens.

- Moist foods, such as vegetables, **fruits**, poultry and **seafood**, microwave well.
- Rich foods, such as bar cookies, moist cakes and candies, are suitable for microwaving because of their high fat and sugar content.
- Reduce regular oven cooking times by 1/2 to 1/3. Check food after minimum time to avoid over-cooking.
- Small amounts of butter or oil can be used for flavoring, but are not needed to prevent sticking.
- Seasonings may need to be reduced. Salt meats and vegetables after cooking.

Covering. In both regular baking and microwave cooking, covers hold in moisture, allow for more even heating and reduce cooking time. In regular ovens, partial covering allows excess steam to escape. Venting plastic wrap or covering with wax paper serves the same purpose when microwaving.

Venting. **After** covering a dish with plastic wrap, you vent the plastic wrap by turning back 1 corner so excess steam can escape.

hanging Food in Oven. When baking in regular ovens, you position foods, such as cake layers or potatoes, so hot air can flow around them. When microwaving, you arrange foods in a ring, so that **all** sides are exposed to microwave energy.

Stirring. In range-top cooking, you stir foods up from the bottom to heat them **evenly**. When microwaving, you stir cooked portions from the outside to the center. Foods that require constant stirring will need **only** occasional stirring when microwaving.

Turning Over. In range-top cooking, you turn over foods, such as hamburgers, so both sides can **directly** contact the hot pan. When microwaving, turning is often needed during defrosting or when cooking certain foods, such as frozen hamburgers.

Standing Time. When you cook with regular ovens, foods such as **roasts** or cakes are allowed to stand to finish cooking or to set. Standing time is especially important in microwave rooking. Note that a microwaved cake is not placed on a cooling rack.

Shielding. In a regular oven, you shield chicken breasts or baked foods to prevent over-browning. When microwaving, you use small strips of **foil** to shield thin parts, such as the tips of wings and legs on poultry, which **would** cook before larger parts.

Arcing. Sparks caused by too much metal in the microwave oven or metal touching the side of the oven or foil that is not molded to food.

Prick Foods to Release Pressure. Steam builds up pressure in foods that are tightly covered by a skin or — membrane. Prick foods, such as potatoes (as you do before **regular** oven cooking), egg yolks and chicken livers, to prevent bursting.

Rotating. **Occasionally**, repositioning a dish in the oven helps food cook more **evenly**. To rotate 1/2 **turn**, turn the dish **until** the side that was to the back of the oven is to the front. To rotate 1/4 **turn**, **turn** the **dish until** the side that was to the back of the oven is to the side.

Basic Microwave Guidelines

Density of Food. In both **regular** baking and microwave cooking, dense foods, such as potatoes, take longer to cook than **light**, porous foods, such as rolls, bread or pieces of cake.

Round Shapes. Since **microwaves** **penetrate** foods to about 1 inch from top, bottom and sides, round shapes and rings cook more **evenly**. Corners receive more energy and may overcook. This may **also** happen when rooking in a **regular** oven.

Delicacy. Foods with a delicate texture, such as custards, are best cooked at lower power settings to avoid toughening.

Natural Moisture of food affects how it cooks. Very moist foods cook **evenly** because microwave energy is attracted to water **molecules**. Food that is uneven in moisture should be covered or allowed to stand so it heats **evenly**.

Piece Size. Small pieces cook faster than **large** ones. Pieces that are similar in size and shape cook more **evenly**. With large **pieces of food**, reduce the power setting for even cooking.

Shape of Food. In both types of cooking, thin areas cook faster than thick areas. This can be controlled in microwaving by placing thick pieces near the outside edge and thin pieces in the center.

Starting Temperature. Foods taken from the freezer or refrigerator take longer to cook than foods at room temperature. Timings in our recipes are based on the temperatures at which you **normally** store the **foods**.

Quantity of Food. In **both types** of cooking, small — amounts **usually** take less time than large amounts. This is most apparent in microwave cooking, where time is **directly** related to the number of servings.

HEATING OR REHEATING GUIDE

NOTE: Use Power Level High (10) unless otherwise noted.



1. Directions below are for heating or reheating already-cooked foods stored in refrigerator or at room temperature. Use microwave-safe **cookware**.
2. Cover most foods for fastest heating. **Exceptions** are some sandwiches, **griddle** foods and baked items.
3. Bubbling around edges of dish is normal, **since** the center is the last to heat. Foods heated to **160°F.** to **165°F.** will provide safe, palatable results.

Adjust temperatures to suit your personal taste.
Let foods stand a few minutes before serving.

4. Be sure foods are heated throughout before serving. Steaming or bubbling around edges of dish does not **necessarily** mean food is heated throughout.

If you use a meat thermometer while cooking, make sure it is safe for use in microwave ovens.

Item	Amount	Power Level	Time
Bakery Foods			
Cake, coffee cake, doughnuts, sweet rolls, nut or fruit bread	1 pica 9 inch cake or 12 rolls or doughnuts	Low (3) Low (3)	1/4 to 1/2 min. 1/2 to 3 min.
Dinner rolls, muffins	1 6 to 8	Medium (5) Medium (5)	10 to 15 sec. 1/4 to 1 min.
Pie: fruit, nut or custard; 1 slice=1/8 of 9 inch pie (use minimum time for custard)	1 slice 9 inch pie	Meal-High (7)	1/4 to 1/2 min. 3 to 5 min.

Beverages

Cocoa, other milk-based drinks (6 oz. per cup)	1 to 2 cups	Meal-High (7)	1 to 4 min.
Coffee, other water-baaed drinks (6 oz. per cup)	1 to 2 cups		1/4 to 2 min.

Meats and Main Dishes

Chicken pieces	1 to 2 pieces		1/2 to 2 min.
Hamburgers or meatloaf (4 oz. per serving)	1 to 2 servings		1/2 to 2 min.
Hot dogs and sausages	1 to 2		1/4 to 1/2 min.
Rice and pasta (m-3/4 cup per serving)	1 to 2 servings		1/4 to 1 min.
Saucy, main dishes: chop suey, spaghetti, creamed chicken, chili, stew, macaroni and cheese, etc. (3/4-1 cup per sewing)	1 to 2 servings		1/2 to 3 min.
Steaks, chops, ribs, meat pieces	1 to 2 servings	Meal-High (7)	1/2 to 3 min.
Thinly-sliced meat (3 to 4 oz. per serving)	1 to 2 servings	Meal-High (7)	1/4 to 1 min.
Topped or mixed with sauce (2/3-3/4 cup per serving)	1 to 2 servings		1/2 to 3 min.

Tip: Cover saucy main dishes with plastic wrap. Cover other main dishes and meats with wax paper. When heating or reheating 3 to 4 servings of meat **slices** or **pieces**, rotate dish 1/2 turn after half of **cooking** time.

Plate of Leftovers

Meat plus 2 vegetables	1 plate		1½ to 2 min.
-------------------------------	---------	--	--------------

Tip: Cover plate of food with wax paper or plastic wrap.

Sandwiches

Meat-cheese filling: with 2 slices of bread	1 to 2 servings	Meal-High (7)	1/4 to 2 min.
Moist filling: Sloppy Joes, barbecue, ham salad, etc. in bun (1/3 cup per serving)	1 to 2 servings	Meal-High (7)	1/2 to 1 min.

Tip: Use paper towel or napkin to cover sandwiches.

soups

Milk-based (6 oz. per serving)	1 to 2 servings	Meal-High (7)	1/2 to 2 min.
Water-based (6 oz. per serving)	1 to 2 servings		1/4 to 2 min.

Tip: Cover soups with wax paper or plastic wrap.

Vegetables

Large pieces or whole: asparagus spears, corn on the cob, etc.	1 to 2 servings		1/4 to 1 min.
Mashed (1/2 cup per serving)	1 to 2 servings		1/4 to 1 min.
Small pieces: peas, beans, corn, etc. (1/2 cup per serving)	1 to 2 servings		1/4 to 1 min.

Tip: Cover vegetables for most even heating.



DEFROSTING GUIDE

1. Food packaged in paper or plastic maybe defrosted without unwrapping. If food is **foil wrapped**, remove foil and place food in cooking dish for defrosting. Most food defrosts **well** using Defrost (3). For more even defrosting of **larger** foods, such as beef, lamb and **veal** roasts, use Warm (1).
2. **After** first **half** of defrosting time, unwrap package and check food. Turn food over, if necessary; break apart or separate food if possible. Shield any warm areas with small pieces of foil.
3. Be sure large meats are completely defrosted before cooking.
4. When **defrosted**, food should be cool but softened in **all** areas. If still **slightly** icy, return to microwave oven very briefly, or let stand a few minutes.

Food	Time	Comments
Breads, Cakes [Power Level: Defrost (3)]		
Bread, buns or rolls (1 piece)	1/4 min.	
Sweet rolls (approx. 12 oz.)	2 to 4 min.	Rearrange after half of time.
Fish and Seafood [Power Level: Defrost (3)]		
Filletts , frozen (1 lb.)	6 to 9 min.	
Shellfish , small pieces (1 lb.)	3 to 7 min.	Place block in casserole. Turn over and breakup after first half of time.
Fruit [Power Level: Defrost (3)]		
Plastic pouch —1 to 2 (10-oz. package)	1 to 5 min.	
Meat [Power Level: Defrost (3)]		
Bacon (1 lb.)	2 to 5 min. per lb.	Place unopened package in oven. Let stand 5 minutes after defrosting. Place unopened package in oven. Microwave just until franks can be separated. Let stand 5 minutes, if necessary, to complete defrosting. Turn meat over after first half of time. Use Power Level Warm (1). Place unwrapped meat in rooking dish. Turn over after first half of time and shield warm areas with foil. After second half of time, separate pieces with table knife. Let stand to complete defrosting.
Franks (1 lb.)	2 to 5 min.	
Ground meat (1 lb.)	4 to 6 min.	
Roast : beef, lamb, veal, pork	9 to 13 min. per lb.	
Steaks , chops and cutlets	4 to 8 min. per lb.	
Poultry [Power Level: Defrost (3)]		
Chicken , broiler-fryer, cut up (2½ to 3 lbs.)	14 to 20 min.	Place wrapped chicken in dish. Unwrap and turn over after first half of time. After second half of time, separate pieces and place in rooking dish. Microwave 2 to 4 minutes more, if necessary. Let stand a few minutes to finish defrosting.
Chicken , whole (2½ to 3 lbs.)	20 to 25 min.	Place wrapped chicken in dish. After first half of time, unwrap and turn chicken over. Shield warm areas with foil. To complete defrosting run cool water in cavity until giblets can be removed.
Cornish hen	7 to 13 min. per lb.	Place unwrapped hen in oven breast-side-up. Turn over after first half of time. Run cool water in cavity until giblets can be removed.
Turkey breast (4 to 6 lbs.)	3 to 8 min. per lb.	Place unwrapped breast in microwave-safe dish breast-side-down. After first half of time, turn breast-side-up and shield warm areas with foil. Defrost for second half of time. Let stand 1 to 2 hours in refrigerator to complete defrosting.



COOKING GUIDE

NOTE: Use Power Level High (10) unless otherwise noted.

Vegetables

Vegetable	Amount	Time	Comments
Asparagus (frozen spears)	1 lb.	5 to 8 min., Meal-High (7)	In 1½-qt. oblong glass baking dish, place 1/4 cup water. Rotate dish after half of time.
(frozen spears)	10+z. package	4 to 7 min.	In 1-qt. casserole.
Beans (fresh green)	1lb. cut in half	10 to 15 min.	In 1½-qt. casserole, place 1/2 cup water.
(frozen green)	10-oz. package	4 to 8 min.	In 1qt. casserole, place 2 tablespoons water.
(frozen lima)	10+z. package	4 to 8 min.	In 1-qt. casserole, place 1/4 cup water.
Beets (fresh, whole)	1 bunch	16 to 22 min.	In 2-qt. casserole, plain 1/2 cup water.
Broccoli (fresh cut)	1 bunch (1¼ to 1½ lbs.)	5 to 9 min.	In 2-qt. casserole , plain 1/2 cup water.
(fresh spears)	1 bunch (1¼ to 1½ lbs.)	7 to 11 min.	In 2-qt. oblong glass baking dish, place 1/4 cup water. Rotate dish after half of time.
(frozen, chopped)	10+z. package	4 to 7 min.	In 1qt. casserole.
(frozen spin)	10+z. package	4 to 7 min.	In 1-qt. casserole, place 3 tablespoons water.
Cabbage (fresh) -	1 medium head (about 2 lbs.)	6 to 10 min.	In 1%-or 2-qt. casserole, place 1/4 cup water.
(wedges)		5 to 9 min.	In 2- or 3-qt. casserole, place 1/4 cup water.
Carrots (fresh, sliced)	1 lb.	4 to 8 min.	In 1½-qt. casserole, place 1/4 cup water.
(frozen)	10+z. package	3 to 7 min.	In 1-qt. casserole, place 2 tablespoons water.
Cauliflower (flowerets)	1 medium head	7 to 11 min.	In 2-qt. casserole, place 1/2 cup water.
(fresh, whole)	1 medium head	7 to 15 min.	In 2-qt. casserole, place 1/2 cup water.
(frozen)	10+z. package	3 to 7 min.	In 1-qt. casserole, place 2 tablespoons water.
Corn (frozen kernel)	10+z. package	2 to 6 min.	In 1qt. casserole, place 2 tablespoons water.
Corn on the cob (fresh)	1 to 5 ears	1½ to 4 min. per ear	In 2-qt. oblong glass baking dish, place am. If com is in husk , use no water; if com has been husked , add 1/4 cup water. Rearrange after half of time.
(frozen)	1 ear	3 to 6 min.	Place in 2-qt. oblong glass baking dish.
	2 to 6 ears	1 to 3 min. per ear	Cover with vented plastic wrap. Rearrange after half of time.
Mixed, vegetables (frozen)	10+z. package	2 to 6 min.	In 1-qt. casserole , plain 3 tablespoons water.
Peas (fresh, shelled)	2 lbs. unshelled	7 to 10 min.	In 1-qt. casserole, place 1/4 cup water.
(frozen)	10-oz. package	2 to 6 min.	In 1qt. casserole, place 2 tablespoons water.
Potatoes (fresh, cubed, white)	4 potatoes (6 to 8 oz. each)	9 to 12 min.	Peel and cut into 1 inch cubes. Place in 2-qt. casserole with 1/2 cup water. Stir after half of time.
(fresh, whole, sweet or white)	1 (6 to 8 oz. each)	1 to 4 min.	Pierce with rooking fork. Place on paper towel on turntable, 1 inch apart in circular arrangement. Let stand 5 minutes.
Spinach (fresh)	10 to 16 oz.	3 to 6 min.	In 2-qt. casserole, place washed spinach.
(frozen, chopped and leaf)	10+z. package	3 to 6 min.	In 1-qt. casserole, place 3 tablespoons water.
Squash (fresh, summer and yellow)	1 lb. sliced	2 to 5 min.	In 1½-qt. casserole, place 1/4 cup water.
(winter, acorn or butternut)	1 to 2 squash (about 1 lb. each)	5 to 9 min.	Cut in half and remove fibrous membranes. In 2-qt. oblong glass baking dish, place squash cut-side-down . Turn cut-side-up after 4 minutes.



CARE AND CLEANING



Keep your oven clean and sweet-smelling. Opening the oven door a few minutes after cooking helps air out the inside. An **occasional** thorough wiping with a solution of baking soda and water keeps the inside fresh.

Do not use sharp-edged utensils on your oven. The inside and outside oven walls **can** be scratched. The control panel **can** be damaged.

BE CERTAIN POWER IS OFF BEFORE CLEANING ANY PART OF THIS OVEN.

How to Clean the Inside

Walls and floor. Some spatters can be removed with a paper towel, others may require a damp cloth. Remove greasy spatters with a sudsy cloth, then rinse with a damp cloth. Do not use abrasive cleaners on oven walls. **NEVER USE A COMMERCIAL OVEN CLEANER ON ANY PART OF YOUR MICROWAVE OVEN.**

Door (inside). Window: Wipe up spatters daily and wash with a damp cloth when soiled. Rinse thoroughly and dry.

Metal and plastic parts on door: Wipe frequently with a damp cloth to remove **all soil**. **DO NOT USE ABRASIVES, SUCH AS CLEANING POWDERS OR STEEL AND PLASTIC PADS. THEY WILL DAMAGE THE SURFACE.**

Removable Turntable and Turntable Support. Occasionally it is necessary to remove the turntable and support for cleaning of the oven floor or turntable. To prevent breakage, do not place the turntable into water just after cooking. Wash it carefully in warm, sudsy water or in the dishwasher. The turntable and support **can** be broken if dropped. Remember, do not operate the oven without the turntable and support in place.

Special note when using Brown 'N Sear Dish:

If grease is present, high heat generated on bottom of a Brown 'N Sear dish may cause the grease to burn onto the oven tray. This may be removed with a cleanser such as Bon Ami® brand cleanser.

After using Bon Ami® brand cleanser, rinse and dry thoroughly following instructions on can. Do not use Bon Ami® brand cleanser on the painted surfaces such as the walls. It may scratch the paint.

How to Clean the Outside

Case. Clean the outside of your oven with soap and a damp cloth, rinse with a damp cloth and then dry. Wipe the window clean with a damp cloth. Chrome trim is best wiped with a damp cloth and then with a dry towel.

Control Panel. Wipe with a damp cloth. Dry thoroughly. Do not use cleaning sprays, large amounts of soap and water, abrasives or sharp objects on the panel—they **can** damage it.

Door Surface. When cleaning surfaces of door and oven that come together on closing the door, use only mild, non-abrasive soaps or detergents applied with a sponge or soft cloth.


Power Cord. If the cord becomes soiled, unplug and wash with a damp cloth. For stubborn spots, sudsy water may be used, but be certain to rinse with a damp cloth and dry thoroughly before plugging cord into outlet.

GROUNDING INSTRUCTIONS



This appliance must be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric

shock by providing an escape wire for the electric current. This appliance is equipped with a power cord having a grounding wire with a grounding plug. The plug must be plugged into an outlet that is properly installed and grounded. (Fig. 1)



WARNING—Improper use of the grounding plug can result in a risk of electric shock. Consult a qualified electrician or service technician if the grounding instructions are not completely understood, or if doubt exists as to whether the appliance is properly grounded.

Where a standard two-prong wall receptacle is encountered, it is your personal responsibility and obligation to have it replaced with a properly grounded three-prong wall receptacle.

Do not under any circumstances cut or remove the third (ground) prong from the power cord.


Use of Adapter Plugs

Usage situations where appliance's power cord will be disconnected infrequently.

Because of potential safety hazards under certain conditions, we strongly recommend against the use of an adapter plug.

However, if you still elect to use an adapter, where local codes permit, a TEMPORARY CONNECTION may be made to a properly grounded two-prong wall receptacle by the use of a UL listed adapter (Fig. 2) which is available at most local hardware stores.

The larger slot in the adapter must be aligned with the larger slot in the wall receptacle to provide proper polarity in the connection of the power cord.



CAUTION: Attaching the adapter ground terminal to the wall receptacle cover screw does not ground the appliance unless the cover screw is metal, and not insulated, and the wall receptacle is grounded through the house wiring. You should have the circuit checked by a qualified electrician to make sure the receptacle is properly grounded.

When disconnecting the power cord from the adapter, always hold the adapter with one hand. If this is not done, the adapter ground terminal is very likely to break with repeated use. Should this happen, DO NOT USE the appliance until a proper ground has again been established.

Usage situations where appliance's power cord will be disconnected frequently.

Do not use an adapter plug in these situations because frequent disconnection of the power cord places undue strain on the adapter and leads to eventual failure of the adapter ground terminal. You should have the two-prong wall receptacle replaced with a three-prong (grounding) receptacle by a qualified electrician before using the appliance.

Use of Extension Cords

A short power-supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord.

Longer cord sets or extension cords are available and may be used if care is exercised in their use.

If a long cord or extension cord is used—

1. The marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance.

2. The extension cord must be a grounding-type 3-wire cord and it must be plugged into a 3-slot outlet.
3. The longer cord should be arranged so that it will not drape over the counter top or tabletop where it can be pulled on by children or tripped over unintentionally.

If you use an extension cord, the interior light may flicker and the blower sound may vary when the microwave oven is on. Cooking times may be longer, too.



QUESTIONS? USE THIS PROBLEM SOLVER

PROBLEM	POSSIBLE CAUSE
OVEN WILL NOT COME ON	<ul style="list-style-type: none">• A fuse in your home maybe blown or the circuit breaker tripped. Replace fuse or reset circuit breaker.● Unplug your microwave oven, then plug it back in.• Make sure 3-prong plug on oven is fully inserted into wall receptacle.
CONTROL PANEL LIGHTED, YET OVEN WILL NOT START	<ul style="list-style-type: none">• Door not securely closed.● STMT pad must be touched after entering cooking selection.• Another selection entered already in oven and CLEAR/OFF pad not touched to cancel it.• Make sure you have entered cooking time after touching MICRO COOK pad• CLEAR/OFF pad was touched accidentally. Reset cooking program and touch START pad• Make sure you entered a code number after touching COOK or the weight after touching AUTO DEFROST.
"Error" APPEARS ON DISPLAY	<ul style="list-style-type: none">• During Cook, Reheat or Popcorn program the door was opened before steam could be detected, or steam was not detected in maximum time.• No steam was detected by sensor within four minutes and 10 seconds after start of Popcorn program.

All these things are normal with your microwave oven:

- Steam or vapor escaping from around the door.
- Light reflection around door or outer case.
- Dimming oven light and change in blower sound may occur while operating at power levels other than high.
- Dull thumping sound while oven is operating.
- Some ~-Radio interference might be noticed while using your microwave oven. It's similar to the interference caused by other small appliances and does not indicate a problem with your oven.

If you need more help...call, toll free: GE Answer Center" / 800.626.2000 / consumer information service

We'll Be There


With the purchase of your new GE appliance, receive the assurance that if you ever need information or assistance from GE, we'll be there. All you have to do is dial—toll-free!

In-Home Repair Service **800-GE-CARES (800-432-2737)**

AGE consumer service professional will provide expert repair service, scheduled at a time that's convenient for you. Many GE Consumer Service company-operated locations offer you service today or tomorrow, or at your convenience (7:00 a.m. to 7:00 p.m. weekdays, 9:00 a.m. to 2:00 p.m. Saturdays). Our factory-trained technicians know your appliance inside and out—so most repairs can be handled in just one visit.

GE Answer Center® **800.626.2000**

Whatever your question about any GE major appliance, GE Answer Center™ information service is available to help. Your call—and your question—will be answered promptly and courteously. And you can call any time. GE Answer Center™ service is open 24 hours a day, 7 days a week.



For Customer With Special Needs... **800.626.2000**

Upon request, GE will provide Braille controls for a variety of GE appliances, and a brochure to assist in planning a barrier-free kitchen for persons with limited mobility. To obtain these items, free of charge, call 800.626.2000.

Consumers with impaired hearing or speech who have access to a TDD or a conventional teletypewriter may call 800-TDD-GEAC (800-833-4322) to request information or service.

Service Contracts **800-626-2224**

You can have the secure feeling that GE Consumer Service will still be there after your warranty expires. Purchase a GE contract while your warranty is still in effect and you'll receive a substantial discount. With a multiple-year contract, you're assured of future service at today's prices.

Parts and Accessories **800-626-2002**

Individuals qualified to service their own appliances can have needed parts or accessories sent directly to their home. The GE parts system provides access to over 47,000 parts... and all GE Genuine Renewal Parts are fully warranted. VISA, MasterCard and Discover cards are accepted.

User maintenance instructions contained in this booklet cover procedures intended to be performed by any user. Other servicing generally should be referred to qualified service personnel. Caution must be exercised, since improper servicing may cause unsafe operation.

YOUR GE MICROWAVE OVEN **WARRANTY**

Staple sales slip or cancelled check here. Proof of original purchase date is needed to obtain service under warranty.

WHAT IS COVERED

LIMITED ONE-YEAR WARRANTY

For one year from date of original purchase, we will provide, free of charge, **parts** and **service** labor to repair or replace **any part of the microwave oven** that fails because of a manufacturing defect.

LIMITED ADDITIONAL NINE-YEAR WARRANTY

For the second through tenth year from date of original purchase, we will **provide**, free of charge, a replacement **magnetron tube** if the magnetron tube fails because of a manufacturing defect. You pay for any service labor charges.

For each of the above warranties:

To avoid any trip charges, you must take the microwave oven to a General Electric Factory Service Center or a General Electric Customer Care® servicer and pick it up following service. In-home service is also available, but you must pay for the service technician's travel costs to your home.

This warranty is extended to the original purchaser and any succeeding owner for products purchased for use in the **48** mainland states, Alaska, Hawaii and Washington, D.C.

All warranty service will be provided by our Factory Service Centers or by our authorized Customer Care® servicers during normal working hours.

Should your appliance need service, during warranty period or beyond, call 800-GE-CARES (800-432-2737).

WHAT IS NOT COVERED

- Service trips to your home to teach you how to use the product.

Read your Use and Care material.

If you then have any questions about operating the product, please contact your dealer or our Consumer Affairs office at the address below, or call, toll free:

GE Answer Center®

800.626.2000

consumer information service

- Improper installation.

If you have an installation problem, contact your dealer or installer. You are responsible for providing adequate electrical, exhausting and other connecting facilities.

- Replacement of house fuses or **resetting** of circuit breakers.

- Failure of the product if it is used for other than its intended purpose or used commercially.

- Damage to product caused by accident, fire, floods or acts of God.

WARRANTOR IS NOT RESPONSIBLE FOR CONSEQUENTIAL DAMAGES.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. To know what your legal rights are in your state, consult your local or state consumer affairs office or your state's Attorney General.

Warrantor: General Electric Company

If further help is needed concerning this warranty, write:

Manager—Consumer Affairs, GE Appliances, Louisville, KY 40225

Part No. 164D2966P135

Pub No. 49-8614

TINS-A489WRR0-G51